MATERIAL SAFETY DATA SHEET COMPLIES WITH OSHA COMMUNICATION STANDARD 29 CFR 1910.1200 AND SUPERFUND AMENDMENTS AND REAUTHORIZATION ACT (SARA) OF 1986 PUBLIC LAW 99-499

SECTION I (IDENTIFICATION)

Manufacturer's Name:

HIGH PERFORMANCE PRODUCTS

1220 Shappert Drive

EMERGENCY PHONE: (815) 985-0441

Machesney Park, IL 61115

Product Name:

HPP 101

Product Classification: Covered Electrode for SMAW

SECTION II (HAZARDOUS INGREDIENTS/IDENTITY INFORMATION)

Important: This section covers the materials of which the products are manufactured. The fumes and gases produced during normal use of this product is covered in Section V. The term "Hazardous" in "Hazardous Material" should be interpreted as a term required and defined in OSHA Hazard Communication Standard 29CFR 1910-1200 and it does not necessarily imply the existence of hazard. The chemicals or compounds reportable by Section 313 of SARA are marked by the symbol #.

DICDEDIENTE	compounds repo	nable by Section 313 of	SARA are marked by the symbol #.	•	
INGREDIENTS	CAS#	% RANGE	OSHA PEL	ACGIH-TLV	CARCINOGENICITY
•			mg/m³	mg/m ³	
Iron	7439-89-6	35-45	5	10 (as Fe ₂ O ₂)	NO
Chromium #	7440-47-3	13-23	.05 (Cr VI)	.05 (CR VI)	YES
Nickel #	7440-02-0	5-15	1	1	·
Manganese #	7439-96-5	1-11	5	1	YES
Silicon	7440-21-3	.1-1.0	5 (as SiO ₂)	3 (aa C:O)	NO
Molybdenum	7439-98-7	1-11	15	3 (as SiO ₂)	NO
Titanium Dioxida			15 15	10	NO
Potassium Silicate		1-11	- 	10	NO
Calcium Carbonate		1-11	Not Regstrd.	5	NO
_	7789-75-5		5 (as CaO)	10	NO
Chromium Oxide		1-11	2.5 (as F)	2.5 (as F)	NO
	1308-38-9	1-11	2.5 (Cr VI)	.05 (Cr VI)	YES
Sodium Solicate	1344-09-8	1-11	Not Regstrd.	5	NO
	68476-25-5	1-11	Not Regstrd.	2	NO
Lithium Aluminum			-		110
Silicate	12068-40-5	1-11	2.0 (as Al)	2.0 (as Al)	NO

SECTION III (PHYSICAL DATA) — NOT APPLICABLE

SECTION IV (FIRE AND EXPLOSION HAZARD DATA)

Nonflammable - Welding are and sparks can ignite combustibles. Refer to American National Standard Z49.1 for fire prevention during welding.

SECTION V (REACTIVITY DATA)

Welding furnes cannot be classified simply. The composition and quantity of both are dependent upon the metal being welded, the process, procedures and electrodes used. Other conditions which also influence the composition and quantity of the furnes and gases to which workers may be exposed include: coatings on the metal being welded (such as paint, plating or galvanization), number of welds and volume of work area, quality and amount of ventilation, position of welder's head with respect to the fume plume, as well as the presence of contaminants in the atmosphere (such as chlorinated hydrocarbon vapors from cleaning and degreasing activities).

When the electrode is consumed, the fume and gas decomposition products are different in percent and form from the ingredients listed in Section II. Fume and gas decomposition products, not the ingredients in the electrode, are important. Decomposition of products include those originating from the volatilization, reaction, or oxidation of the materials shown in Section II plus those from the base metal, coating, etc. as noted above. These components are virtually always present as complex compounds and not as metals (Characterization of Arc Welding Fume: American Welding

Reasonably expected fume constituents would include complex oxides of iron, chromium, manganese, silicon, nickel and molybdenum. Fume limit for Cr VI (0.05 mg/M²) may be reached before limit of 5 mg/M³ for general welding fumes is reaches. Monitor Cr VI level. Gaseous reaction products may include carbon monoxide and carbon dioxide. Ozone and nitrogen oxides may be formed by the radiation from the arc in TIG welding.

One recommended way to determine the correposition and quantity of furnes and gases to which workers are exposed is to take an air sample inside the welder's helmet, if worn, or in the worker's breathing zone. ANSI/AWS F1.1 available from the American Welding Society. P.O. Box 351040, Miami, FL 33135.

SECTION VI (HEALTH HAZARD DATA)

Threshold Limit Value: The ACGIH recommended general limit for welding fume NOC (Not Otherwise Classified) is 5 mg/M?. The ACGIH 1984-85 preface states: "The TLV-TWA should be used as guides in the control of health hazards and should not be used as firm lines between safe and dangerous concentrations." See Section V for specific fume constituents which may

Effects of Overexposure: FUMES AND GASES can be dangerous to your health. Primary route of exposure is inhalation of fumes. Preexisting respiratory or allergic conditions may be aggravated in some individuals. SHORT-TERM (ACUTE) OVEREXPOSURE to welding fumes may result in discomfort such as: dizziness, nausea, or dryness or irritation of nose, throat, or eyes. LONG-TERM (CHRONIC) OVEREXPOSURE may lead to siderosis (iron deposits in the lungs) and is believed by some investigators to affect pulmonary function. ARC RAYS can injure eyes and

Emergency & First Aid Procedures: Call for medical aid. Employ first aid techniques recommended by American Red Cross.

CARCINOGENICITY When Present

NTP?

I ARC MONOGRAPHS

OSHA REGULATED Cr

Cr. Ni

SECTION VII (PRECAUTION FOR SAFE HANDLING AND USE/APPLICABLE CONTROL MEASURES)

Read and understand the manufacturer's instructions and the precautionary label on this product. See American National Standard Z-49.1. Safety in Welding and cutting, published by the American Welding Society, P.O. Box 351040, Miami, FL 33135 and OSHA Publication 2206 (29CFR 1910), U.S. Government Printing Office, Washington D.C. 20402 for more detail on the

Ventilation: Use enough ventilation, local exhaust at the arc, or both to keep the fumes and gases below the TLV's in the worker's breathing zone and the general area. Train the welder to keep his head out of the fumes.

Respiratory Protection: Use respirable fume respirator or air supplies respirator when welding in confined space or where local exhaust or ventilation does not keep exposure below TLV. Eye Protection: Wear helmet or use face shield with filter lens. As a rule of thumb, start with a shade darker to see the weld zone. Then go to the next lighter shade which gives sufficient view of the weld zone. Provide screens and flash goggles, to shield others.

Protective Clothing: Wear head, hand and body protection which help to prevent injury from radiation, sparks and electrical shock. See ANSI Z-49.1. At a minimum, this includes welder's gloves and a protective face shield and may include arm protectors, aprons, hats, shoulder protection, as well as dark substantial clothing. Train the welder not to touch live electrical parts and to insulate himself from work and ground.

Waste: Dispose of any grinding dust or waste residues in accordance with EPA or local regulations.